



French Door

Installation

**HANDLE
WITH CARE**

To Install French Doors - French Door Size: 34" X 77 3/4" to fit a 6' French Door

- 1) Mount the 2 Hinge Bars to the inside door jambs using the hinges and screws provided.



1

- 2) Once the bars are mounted, slide the door that is to be the non-operable door into the Hinge Bar. Place the door in a closed position to square the door and attach the Hinge Bar with 3 screws.



2

- 3) Slide the Astragal over the door, the weather strip should be out. Close the door to determine if the Astragal needs to be notched.




3

- 4) Once the Astragal has been notched (if necessary), slide the operable door into the other hinge bar. Close both doors, space the door and or Astragal as necessary, attach the Astragal and hinge bar with screws provided.



4

- 5) Open the non-operable door and extend the locks on the Astragal. Place a small amount of caulk onto the Astragal locks. Close the door again and once in place, extend the locks. This will mark where you need to drill for the locks. Using a 7/23 drill, drill the holes where marked.



5

Fullview French Doors



Pull Style Handle Closure Kit Installation Instructions

To Install the Handle Assembly:

A - Measure & Mark

- 1) With the screen door in the CLOSED POSITION, line up the provided Latch assembly with the Striker Plate on the inside of the Astragal at height to clear the main door knob. Place the Latch against the Astragal using it as a template to determine top & bottom screw holes. Mark spot holes to be drilled.

- 2) Use provided 3-Hole Template as a tool to determine the center hole position for the Latch/Hardware by placing it over where the top and bottom holes have just been marked in step 1.

B - Install

- 3) Drill three 5/16" or 1/4" holes STRAIGHT through door for easy installation & assemble outside components.
- 4) Slide spring onto spindle and insert into handle. Slide into the outside of door and fasten with 1-1/4" screws. Please refer to Diagram B if needed.
- 5) Attach appropriate solid strike to the jamb. On half Astragal you will generally use the 1/2" solid strike. On Full or Adjustable use the 1/4" solid strike.

